# Instructions Builder



B u i l d e r i n f o @ 3 d p r i n t e r 4 u . n l + 3 1 2 5 2 - 3 4 6 1 6 2

+ 3 1 2 5 2 - 3 4 6 7 2 7



# CONTENT

1.	Specifications	2
2.	Overview Builder	2
3	Items that come with the builder:	3
4.	Unpacking the Builder	5
5.	Installing drivers	7
5.1	1 Installing drivers on windows 8	9
6.	Software	9
6.1.	1. Pronterface	10
6.	Check bed Height	12
7.	Maintenance	13
8.	Uw eerste print met Pronterface	gedefinieerd.



# 1. SPECIFICATIONS

- Measurements Builder: 385x370x400 mm (Length x with x height)
- Material casing: Powdercoated steel
- Color Casing: Red/Black/Bronze
- Printtableau: removable
- Printmaterial: PLA 1.75 mm
- Standaard resolution: 0,15 mm
- Capacity: 120 watt
- Builder extruder single extruder head automatic PLA Feed
- Transportweight: 17 kg
- Packaging: Cardbord
- software: opensource



2. OVERVIEW BUILDER



- 1. Wire-feed clip
- 2. Fillament axe
- 3. Fillament
- 4. Tube
- 5. Mobile extruder





#### 3 ITEMS THAT COME WITH THE BUILDER:

Items mentioned below come with the builder.

Order Filament with your printer! The printer does not come equipped with filament!

Multiple colors of filament are available online in our webshop : <a href="https://www.3dprinter4u.nl/webshop/">www.3dprinter4u.nl/webshop/</a>





### 4. UNPACKING THE BUILDER

1. Place the box on a flat service. Open the box and remove the protective material.



2. Lift the Builder from the box. Grab The Builder by the frame and place it on a steady surface.



3. Remove the foil from the print-tableau. Place the Tableau in the machine fitting the corners on the screws in every corner. Make sure to press down making sure the tableau is all the way down on the screws



4. Remove the tie raps which hold the extruder.





5. Mount the Filament-arm on the side on one of three sides. Then place the clip on the top edge of the machine..





6. Remove the plastic from the filament and place the role on the Filament arm. Now feed the filament thru the clip and tubeing.



7. Feed the filament trhu the tubing until it reaches the extruder. Open the lid of the extruder by sqeezing the spring-screws. Feed the filament all the way into the extruder. Close the lid and make sure the spring-screws return in the correct position.



- 8. Make sure the switch on the Builder is turned off. Now Plugin the builder.
- 9. Do not connect the usb cable before downloading and installing the drivers.



# 5. INSTALLING DRIVERS

Users should install the drivers before installing printersoftware.

Find the drivers you need on <u>www.3dprinter4u.nl/installatie/</u>

Click on "install". In some cases security warnings popup!

Install drivers in spite of the popups

Virtual Serial Driver	Vindows-beveiliging
USB Communications Device Class Abstract Control Model	De uitgever van dit stuurprogramma kan niet worden gecontroleerd
This installer will add a driver information file (INF) for all USB Virtual Serial devices using the USB Communications Device Class with Abstract Control Model. Windows already has this driver (USBSER.SYS). This INF merely tells Windows to load its driver when you connect a USB device using the CDC ACM protocol.	Dit stuurprogramma niet installeren Ga naar de website van de fabrikant voor een bijgewerkte versie van het stuurprogramma voor het apparaat.
The Unsigned Driver warning will appear, because this is not signed by Microsoft. You must run this installer with Administrator Privileges to successfully install.	Dit stuurprogramma toch installeren Installeer alleen stuurprogramma's van de website van de fabrikant of van ee schijf. Met niet-ondertekende software van andere bronnen kan uw compute worden beschadigd of kunnen gegevens worden gestolen.
	Details weergeven

Once drivers are finished installing click "done".

Finished			
Successfully Insta	lled		
Driver INF	Installed		
When you conned "Found New Hard automatically.	t a Virtual Serial devie ware Wizard" will now	ce (using CDC ACM) the able to find this driv	ne /er
Because this INF	is not signed by Micro	soft, you must still cho	ose
1		Ind approve the lice ou	ion i
it in the Found Ne though it only loa	ds Microsoft's own US	BSER.SYS driver!	CII
it in the Found Ne though it only loa	ds Microsoft's own US	BSER.SYS driver!	CII
it in the Found Ne though it only loa	w naroware wizard, a ds Microsoft's own US	BSER.SYS driver!	en



Once drivers are installed connect the USB cable connecting the Builder to your computer.

Your computer will connect to the machine and proposes to install the drivers. Click on this tab to install the drivers.



Once the configuration is completed the popup below will appear.





5.1 INSTALLING DRIVERS ON WINDOWS 8

- 1. Windows Key + R
- 2. Enter shutdown.exe /r /o /f /t 00
- 3. Click the "OK" button
- 4. System will restart to a "Choose an option" screen
- 5. Select "Troubleshoot" from "Choose an option" screen
- 6. Select "Advanced options" from "Troubleshoot" screen
- 7. Select "Windows Startup Settings" from "Advanced options" screen
- 8. Click "Restart" button
- 9. System will restart to "Advanced Boot Options" screen
- 10. Select "Disable Driver Signature Enforcement"
- 11. Once the system starts, install the Arduino drivers as you would on Windows 7

Steps to install driver after Driver Signature Enforcement has been disabled:

- 1. Right click the Unknown Device in Device Manager
- 2. Select Update Driver Software
- 3. Select Browse my computer for software
- 4. Click Browse button

5. Select the Drivers folder under the location of your Arduino software installation. (Do not select the FTDI folder inside the Drivers folder)

- 6. Click OK
- 7. Click Next

#### 6. SOFTWARE

To start printing users will need software.

The builder can be controlled using Open-source software such as CURA, PRONTERFACE and REPETIER

We Added PRONTERFACE to our manual because it is considered the "most basic" printer software. Please feel free to experiment with all other possible software.

All can be downloaded for free.



#### 6.1 PRONTERFACE

Image below shows the interface.



To connect the Builder with your computer make sure you know which COMPORT it is connected to. Usually Pronterface selects the corresponding COMPORT automatic. U can check this by selecting the bitrate 250000 and clicking "connect".



The Status-area will inform you whether or not the printer is currently online.



		X



Troubleshooting connection:

Stuck in "connecting" mode?

Select a different COMport.

Find out which COMport u should use

- Browse to tools / configuration
- Machines / device management
- Ports
  - Check which port "USB Serial (Communication Class, Abstract Control Model) (COM.....)



Make sure the Port matches the one selected in Pronterface.



#### 7. CHECK BED HEIGHT

The height of the bed is vital for printing accurate 3d objects. The Bed is adjusted before the Builder is shipped out. During transport the bed height might be affected.

#### Always check the bed height before starting to print an object!

- 1. Make sure that the bed fits over the screws in the corner. Do this while the extruder is cold
- 2. Add a layer of Tape to the bed. Tape should be replaced every 5-10 prints to ensure good adhesion.
- 3. Check the Bed height by sending the extruder to all four corners. At every corner the space between the extruder and bed should be 0.2MM. A good reference is fitting a piece of paper in between. The piece of paper should barely fit but should NOT get stuck in between.
- 4. If needed adjust the bed, and repeat step 3. Until the required 0.2MM had been reached.
- 5. **Tip**: most software offers the option of printing a "calibration-square".





#### 8. MAINTENANCE

Oil the moving parts of the builder. After oiling the parts will have to move some time to distribute the oil evenly. When distributed the oil will make sure the parts move smoothly.

The extruder needs maintenance as well. Due to feeding the wire thru some dust may build up under the lid. Remove this dust in order to prevent the filament feed to get stuck.

Tiny pieces of filament residue may get stuck to the extruder.

#### **!!WARNING!!**

Make sure the extruder has cooled down before attempting to clean it!



#### 9. MAKING YOUR FIRST PRINT WITH PRONTERFACE

The first step before printing a model is to convert a STL-file to a G-code. This is done by a small program known as a "slicer". U can start up a slicer from the Pronterface menu -> select "settings" -> "Slicing settings".\*



\*When selected the Configuration wizard should startup. If this doesn't happen select "help"-> Configurations wizard en follow instructions

Configuration Wizard		Configuration Wizard	
	Welcome to the Slic3r Configuration Wizard		Firmware Type
Welcome     Firmware Type     Bed Size     Nozzle Diameter     Filament Diameter     Extrusion Temperature     Bed Temperature     Finish	Hello, welcome to Slic3rl This wizard helps you with the initial configuration; just a few settings and you will be ready to print. To import an existing configuration instead, cancel this wizard and use the Open Config menu item found in the File menu. To continue, click Next.	Welcome     Firmware Type     Bed Size     Nozzle Diameter     Filament Diameter     Extrusion Temperature     Bed Temperature     Finish	Choose the type of firmware used by your printer, then click Next. G-code flavor: RepRap (Marlin/Sprinter) •
	< Back Next > Cancel		< Back Next > Cancel
Configuration Wizard		Configuration Wizard	
	Bed Size		Nozzle Diameter
Welcome     Firmware Type     Ged Size     Nozzle Diameter     Filament Diameter     Extrusion Temperature     Bed Temperature     Finish	Enter the size of your printers bed, then click Next. Bed size: x: 220 y; 220 mm	Welcome     Firmware Type     Bed Size     Nozzle Diameter     Fiament Diameter     Extrusion Temperature     Bed Temperature     Finish	Enter the diameter of your printers hot end nozzle, then click Next. Nozzle diameter: 0.4 mm
	< Back Next > Cancel		< Back Next > Cancel
Configuration Wizard		Configuration Wizard	
Welcome     Firmware Type     Bed Size     Nozzle Diameter     Filament Diameter     Extrusion Temperature     Bed Temperature     Finish	Filament Diameter Enter the diameter of your filament, then click Next. Good precision is required, so use a caliper and do multiple measurements along the filament, then compute the average. Diameter: 1.75 mm	Welcome     Firmware Type     Bed Size     Nozzle Diameter     Filament Diameter     Extrusion Temperature     Bed Temperature     Finits	Extrusion Temperature Enter the temperature needed for extruding your filament, then click Next. A rule of thumb is 160 to 230 °C for PLA, and 215 to 250 °C for ABS. Temperature: 190
	< Back Next > Cancel		< <u>Back</u> <u>Next</u> <u>Cancel</u>
Configuration Wigard	×	Configuration Winned	
Configuration Wizard	Bed Temperature	Configuration Wizard	Congratulations!
Welcome     Firmware Type     Bed Size     Nozzle Diameter     Filament Diameter     Extrusion Temperature     Bed Temperature     Finish	Enter the bed temperature needed for getting your filament to stick to your heated bed, then click Next. A rule of thumb is 60 °C for PLA and 110 °C for ABS. Bed Temperature: 0 *C	Welcome     Firmware Type     Bed Size     Nozzice Diameter     Filament Diameter     Extrusion Temperature     Bed Temperature     Finish	You have successfully completed the Slic3r Configuration Wizard. Slic3r is now configured for your printer and filament. To close this wizard and apply the newly created configuration, click Finish.
	< <u>B</u> ack <u>N</u> ext > <u>C</u> ancel		< Back Einish Cancel



.

.

After completing the wizard u can Load up your STL file in order to create a GCODE. Once the code is generated select "export G-code".

ater	Print Settings	Filament Settings	Printer Settings					
			O More	Certain Contraction Contraction	© 45°	🦻 45°	Rotate	Scale
			Name				Cop	Sc
			Stretchle	t (1).stl			1	10
	<u> </u>	J	•		III		0	Þ
			Add		Autoa	rrange	Export G-	code.
	X =	110	Delete		XDelete	e All	Export ST	ïL

Load the Gcode in Pronterface and click "Print"

For tons of shared designs check out <u>www.thingiverse.com</u> or <u>www.turbosquid.com</u>



